


**Display targets
in real time on
your route**



SOLO mode



GROUP mode

Geolocate your routes and reference your finds with GO TERRAIN!

The four main advantages of GO TERRAIN:


- 1** Connect your XP detector to GO TERRAIN with Bluetooth to display your targets in real time on your route with their ID
- 2** Save and consult all your routes, alone or with several people (group mode)
- 3** See your colleagues' positions, routes and finds in real time
- 4** Share and expand your database for a terrain over time

CONTENTS

PROFILE CONNECTION REGISTRATION	4	GROUP MODE	15
Method number 1	4	Group mode/Contact request	15
Method number 2	4	Group activity	16
Application tutorial	4		
HOME PAGE	5	OTHER FUNCTIONS	17
Diagram of welcome functions	5	Mark out a search zone	17
CURRENT ACTIVITY (SOLO MODE)	6	Display path line and target history	18
Activity	6	Profile	19
UPPER PART OF APPLICATION	7	PACK FUNCTIONS	20
General menu	7	Standard	20
Connection to the detector	8	Premium	20
Settings	9		
ACTIVITY SEQUENCE	10		
Adding a target	10		
Consult/Change/Delete	11		
End of activity	11		
Managing activities	12		
Synchronising your activities	13		
Exporting your activity data	13		
Managing targets	14		



✉ E-mail contact:
contact@xpmetaldetectors-media.com



Create an account when downloading the application or connect if you already have one.

There are **two ways** of creating an account:

TRADITIONAL METHOD

Fill in a form requesting miscellaneous information:

- Name
- First name
- E-mail (important to be able to recover your forgotten password)
- Password
- Telephone number (to communicate with your colleagues by SMS via CONTACTS)
- Receive the XP Metal Detectors newsletters and keep abreast of XP news and new features
- Mandatory acceptance of General Terms and Conditions of Use

APPLE METHOD

Control using Apple ID by password, fingerprint or Face ID, depending on the iOS version.


You can connect once the account has been created.

POP-UP:

When launching the app, several pop-ups will appear to authorise:

- Mandatory GPS position (geolocation of finds and creation of route)
- Bluetooth activation (connection to DEUS II/DEUX/ORX)
- Authorisation for the mike and camera (adding photos, videos, audio recordings for the finds)

Successive images help you to understand the main **GO TERRAIN** features.



HOME PAGE



ACTIVITY PAGE

- **Red** = XP detector disconnected
- **Green** = XP detector connected

Click on the map to enter or exit full screen mode.
In full screen mode, click on your position to add a find.

Target meter
Click to list your finds

Map mix
Time meter

Distance covered

Scale

Green line:
Save mode

Red line:
Activity paused

▶ Activity/Pause


- 📍 Active: adding targets (p. 10)
- ⚙️ Paused: change your settings (p. 17)

Base map:

- **Google:** normal - satellite - ground (ANDROID)
- **MapKit :** normal - satellite - hybrid (iOS)
- **OPENSTREETMAP** (Android - iOS)

GO ■ Start/Stop activity

MENU



App features:

- **Map** (return to home page)
- **My activities** (list of your activities)
- **My targets** (list of your finds)
- **My contacts** (list of friends in GO TERRAIN)
- **Notifications** (acceptance of a contact, a group activity, etc.)
- **About GO TERRAIN** (XP site, tutorials, General Terms and Conditions)
- **GO TERRAIN, DEUS II, DEUS, ORX manual**
- **GO TERRAIN PACK choice** (access to additional features)
- **Application version**

GO TERRAIN CONNECTION TO THE XP DETECTOR

Everyone can use GO TERRAIN by adding targets to the map manually, but the connection to your XP detector has the advantage of saving the targets detected in real time on the route automatically.

GO TERRAIN has to be synchronised with your XP Detector in advance:

- 1 Activate Bluetooth on your smartphone.
Launch GO TERRAIN and click on the picto: 
- 2 Click on **Search DEUS/ORX**: 
- 3 Check that your XP Detector is in GO TERRAIN **AUTO** mode (OPTION>SETTINGS>GO TERRAIN>AUTO or PUSH).
- 4 Sweep a target in front of the disc at least three times in five seconds. GO TERRAIN then has to suggest the number of the disc with which to pair.
- 5 Click on the serial number of the disc and you will then be paired.



To pair the XTREM HUNTER accessory, After clicking on **Search DEUS/ORX**, just long press  on your remote and click on the serial number that appears.

There are two possible ways of transferring target ID from your XP Detector to GO TERRAIN:



1 - GO TERRAIN AUTO (OPTION/SETTINGS/GO TERRAIN)

In activity mode, the detector automatically sends the data to the application so that they are saved directly to the map. This option can be used on terrains with little pollution to avoid saturating the map.

2 - GO TERRAIN PUSH (OPTION/SETTINGS/GO TERRAIN)

When displaying the target ID on the remote control, hold the central button down for five seconds to send the target to the application. You can thus control the targets you wish to see on the map.

Ferrous items (0-19) are displayed by black dots to avoid saturating the display.

The XTREM HUNTER works only in PUSH mode. At any time during an activity, a long press on  will mark your position by sending an ID of 99 to the application.

SETTINGS

Activate/deactivate Bluetooth

Synchronise/desynchronise your XP Detector


T.ID display ON/OFF

Ferrous item display ON/OFF

GO TERRAIN AUTO:

Sweep the target 3 times in 5 s to save it in your activity (the number of sweeps and the time interval can be changed).

The target will only be sent to GO TERRAIN if the three sweeps have an identical target ID.



You can use GO TERRAIN to display target ID instead of the remote control, for example if you only have the WS6 MASTER helmet.




Target and ground ID received from the XP Detector

GPS precision

Target added automatically

Target added manually



ADDING TARGET

← ADD FIND

Tap on map to change location

43°27'26.21518" N 1°31'50.38773" E - 31T 381128 4812646

Name

12 May 2023 11h09

Icons

Icon size adjust

Details

Size in

Target ID

Time period Unknown

Material Unknown

Description

Medias

SAVE FIND

The target is positioned on your location. Change its localisation by clicking on the map and repositioning it.

Target's GPS coordinates.

Change the target name; the date and time is displayed by default.

The target icon is illustrated by an orange circle. You can however change it by selecting personalised icons specific to your activity (coins, jewels, militaria, meteorite, fossils, fungus, viewpoint, etc.).

Reduce or enlarge the icon size based on their importance.

Information about the find. Enter its size, ID (T.ID), era, material and a written description of the target or the environment.

MEDIA:

For each find you can add:

- 3 photos max., live or from your library.
- 2 audio recordings
- 2 one-minute videos max.



Any photo you add to the find is taken as a thumbnail and is displayed on the path line instead of an icon.

SAVE THE TARGET ON YOUR ROUTE

CONSULT/CHANGE/DELETE

1

9 finds

or

Access your targets via the meter or directly on the map.

2

or

Click on your list or the map to display your target.

3

Delete your targets

Change the information

4

- Choice of icons
- Details (Size, T.ID, Era, Material, Description)
- Media (Photo, Sound, Video)

Save the changes:


END OF ACTIVITY

Stop the activity and confirm.


You can:

- Rename it.
- Synchronise to back up your activity to the encrypted XP Cloud. (**PREMIUM** pack)
- Look through the list of your finds (change or delete targets).
- Save or do not save the activity.


MANAGING ACTIVITIES




Consult your activities from the menu ☰



This filter ☹ helps you in searching for your finds and activities per theme.



Search for your finds and activities directly on the map.




Consult/Change/Delete the finds of an activity by clicking on an activity and then on Display targets.



Repeat a previous activity.
To make a clearer distinction between repeated activities, use ⚙ to change the colour and/or thickness of the activity path line when it is paused.

SYNCHRONISING YOUR ACTIVITIES



Upgrade to **PREMIUM** to synchronise your activities with the Cloud and keep your data should the telephone change or the application disconnect.

MENU > MY ACTIVITIES > select the activity to be synchronised.



Make sure you have good 4G cover when synchronising so that the data is sent correctly to the Cloud.

CAUTION:

In case of disconnection, data not synchronised with the Cloud and therefore only stored locally in the application database, such as activities, targets and path lines, will be deleted. Only the user account information will be kept.

Note that the Standard Pack does not have the Cloud use option.



Data exchanges take a certain time to synchronise with the Cloud. Please be patient.


EXPORTING YOUR ACTIVITY DATA

KML:


Format used to manage the longitude/latitude geographical data display in Here Maps, Google Earth, Maps, Mobile, etc.

GPX:


Open XML format used by most GPS or other applications of this type to import or export waypoint or trace GPS coordinates between each other. This type of file can also be changed or viewed with a text editor equipped with an XML plug-in.



MANAGING TARGETS




Consult your targets from the menu ☰



Consult/Change/Delete the finds of an activity:
Select the Target.

For the finds, a third **GALLERY** tab brings together all the photos of your finds.



Delete your target 🗑️

Change your target information ✎️

Information about your target.

GROUP MODE/CONTACT REQUEST

At start-up, choose to launch a solo  or group  activity.


2 methods of requesting contact with a colleague and creating a group:

1 MENU > MY CONTACTS > ADD A NEW CONTACT

> search for your friend and send him a request by clicking  and confirm.

**2 From Home, activate group mode by clicking on the tab so that it becomes **
 Click on:

GO > ADD CONTACT > search for your friend and send them a request by clicking  and confirm. When they accept, you can add them directly to the group and send them a group activity request.




You are therefore hosting the session and can thus start the group activity and stop it at any time.

GROUP ACTIVITY

3G/4G/ 5G phone network mandatory (4G and 5G advisable)

Group mode requires all members to have a **Premium** pack.

You can invite up to five contacts to join your group, a total of six people at most. Finds and path lines can be shared and displayed on every smartphone in the group in group mode.



The server synchronises the data between the users in a same group in real time. The data are stored on the secure server and locally (application database). The group activities can be retrieved.

The data exchanged in real time are therefore:

- User path lines (path lines, number of km covered)
- User finds (number, information and details of each target, videos, photos, etc.)



Any participant can leave the group when he wishes. However, if the host stops the activity, all other group members are stopped.




Only the host can continue the group activity; he can create a new group and thus feed and expand the activity. However, other people in the group can display the previous group activity (path lines and finds) using the settings.

MARK OUT A SEARCH ZONE

Make sure not to leave the detection zone by marking out your search zone accurately. Your telephone will vibrate if you leave.


Mark out your zone before launching the activity:

- Click on the  tab and then click on  to mark out your search zone directly on the map.
- You can leave settings and start/go back to your activity.




DISPLAY PATH LINE AND TARGET HISTORY

- **Current activity:** only displays the path line currently created in the activity.
- **Today's activity:** you travel a route in the morning and stop it for a lunch break. During a new activity in the afternoon, you can display the morning's activity to expand the database.
- **Selected activities:** select your desired number of activities to be sure you avoid going over the same place, even a few months later.




All the data are encrypted and only available to the holder of the GO Terrain account



PROFILE

Access
your profile



Disconnect or delete your account.



Disconnecting will delete all unsynchronised data (activities and linked targets) in the Cloud.


Deleting the account deletes the profile, activities and targets. But the subscription is managed by the store (Google Play/App Store). To cancel your subscription, go to "Payment and Subscription/Purchases" in the store.

Mobile number so that your contacts can contact you via SMS through the application

Password change.

Automatic synchronisation of data in the Cloud (**PREMIUM** pack)

Keep up-to-date with the latest upgrades



STANDARD

15 days free, then only €4.99/year

- Unlimited solo activities
- Unlimited finds
- Connection to DEUS II/DEUX/ORX
- Access to maps:
 - Google Maps (Normal, Satellite, Ground)
 - OpenStreet Map

STANDARD 4,99€ for 1 year

- Free 15-day trial period
- Unlimited solo activity
- + Connection to DEUS
- + Access to free maps
- + Possibility of deleting activities
- + Possibility to continue an activity

[I subscribe](#)**PREMIUM**

€9.99/year - **STANDARD PACK** with in addition:

- **Access to group mode**
- **Connection to the Cloud** (saving finds, activities and group mode)

PREMIUM 9,99€ for 1 year

- All STANDARD benefits
- + Unlimited finds
- + Group activity
- Synchronisation on the Cloud
- Map available in offline

[I subscribe](#)

Leave us a comment by clicking on the App Store or Google Play logo or via:

- App Store: <https://apps.apple.com/us/app/go-terrain/id1419674707>
- Google Play: <https://play.google.com/store/apps/details?id=com.bleu122.goterrain>

Do you have a question about GO TERRAIN?

Join [our FACEBOOK group \(Go Terrain\)](#)

and discuss the application with the other members.

E-mail contact: contact@xpmetaldetectors-media.com



Click here to join the group!