

Updates to the V3.0 manual

- Reactivity 2.5, this new reactivity level is fast and deep, offering a good compromise especially when searching new terrain.
- Program No10 GOLD FIELD: Improved Audio Response and reactivity.

 Goldfield will give excellent results especially when combined with the new HF coils...Now difficult targets can easily be detected in mineralized ground. The Tone menu has been removed.
- $\bullet \ Lower \ discrimination \ range: For \ those \ \ who \ want \ more \ control \ over \ ferrous \ targets.$

Negative discrimination of 0 to -6.4 makes it possible to locate previously rejected ferrous items, the lower discrimination range can also enhance the signature from deep targets which may have in the past been ignored. These new options also offer a big advantage when searching for specific targets such as ceramics or even meteorites.

- Ground Effects: Improved Tracking.
- Improved display and signal processing compatible with the new HF 21 frequencies. The display now has the ability to handle detection frequencies up to 81kHz (18kHz before), now with 7 frequency offsets (compared to 3 previously).
- DEUS is now compatible with a smartphone: Target information and other data can be sent by radio link to a smartphone. An app will soon be available to unlock these features.
- New program No9 "HOT": "Pro setting" this is a find everything program, based on the Full Tone audio mode with a very low discrimination. Hot is a very interactive program offering excellent feedback and target information.
- New program No6 "DEEP": "Pro setting" for locating deep targets, with moderate discrimination and specific signal processing.
- Improved Non motion / static mode: Non motion modes are now more advanced offering better overall performance, with an improved sensitivity to small targets.
- New processing: Dual processing power improves navigation and a range of other parameters. remote and headset battery life has slightly decreased to 18 and 20 hours respectively.
- Normalization display is now a menu feature on the WS4 and WS5 headphones.
- The headset volume is now stored when switched off.
- The coil name in the coil menu have gone, the serial number is now used as the coil reference.
- Erasing a coil from the list is done by replacing all characters with 0.
- Audio tone can now be raised up to 993 hertz
- Target Normalization mode is on by default (Normalization is not active with HF coils)
- When turning OFF the remote control to use only the wireless headphone, the coil restart

New Optional High Frequency coils:




Interchangable battery mounted in the lower stem

The v4 manual is available soon from our web site: www.xpmetaldetectors.com

NEW PROFILE : OSCILLOSCOPE XY DISPLAY


OPTION > CONFIGURATION > PROFILE




OSCILLOSCOPE DISPLAY XY: The target signature is displayed on an oscilloscope. The XY screen provides a visual assistance and may improve the identification of difficult targets.

For example: The identification of targets that do not have a precise signature (some ferrous, cans ...). The XY profile can be selected as the default display.


The display magnification of the XY trace has 10 levels of adjustment using the Zoom function.



XY screen target examples:




Typical non ferrous Signature for coins.




Typical non ferrous signature for foil.


OPTION MENU GB



Typical signature for rejected ferrous.




Typical signature for cans and difficult to reject large ferrous items.



Typical signature from ferrite and ceramics.

Zoom XY mode



- 1 Press the Pinpoint button for 2 seconds to display the zoom function.
- Adjust the zoom by pressing the or key

PINPOINTER MI-6

When connected the MI-6 pinpointer transmits its audio signal directly to the DEUS, a new menu will now be available with extended functions.

Pairing the remote control with Pinpointer




- 1 Choose OPTION
- Press and select PINPOINTERS
- 3 Select PAIRING

Turn on the MI-6, then hold the button down for 8 seconds

4 Once paired the MI-6 will operate with the DEUS.

When pairing, the MI-6 automatically switches to program 7 (DEUS). This program will only work with the DEUS. Program 7 will not generate any sound or vibration.


Remove the MI-6 from the menu



Choose REMOVE and press YES.

Note: To use the MI-6 without the DEUS, select programs 1 to 6 on the MI-6 menu. To change program: Switch MI-6 on - press the button for 5 seconds, a melody indicates that you have entered the program selection mode, press to correspond with the desired program number (eg press 2 times for program 2). After 2 seconds the melody indicates the MI-6 has returned to the search mode.

Recover a lost MI-6



Find your pinpointer within a radius of 25 meters, even if switched off and missing after several weeks.

- 1 Press RESEARCH
- 2 The pinpointer will start sounding with a flashing LED.
- 3 Press the pinpointer button and return to the search mode with

Pairing the headphones at the MI-6



- 1 Press until you reach **COIL**.
- Press to reach **PP**, then press 3 seconds. **PP** flashing.
- III Turn on the MI-6, then hold the button down for 8 seconds. PP is paired.
- 4 Press MENU

Remove the MI-6 at the headphones


- 1 Press until you reach **COIL**.
- 2 Press to reach **PP**, then press 3 seconds; **PP** flashing.
- 3 Press MENU

MI-6 active display screen



The MI-6 pin pointer - Extended functions

Sensitivity




The MI-6 has 50 levels of sensitivity via the remote control.

Press (-) or (+) The MI-6 has 50 levels of sensitivity via the remote control.

Note: For precise object location, low sensitivity levels, such as prog 1 and 2, are recommended. The high sensitivity level (prog 3) is for cache location or searching in walls and furniture.

Retune At any time, you can re-calibrate the MI-6 by pressing the button very briefly while away from any metallic source. On mineralized soil, salt water, re-calibrate it in contact with the ground. To localize detection range, re-calibrate (de-tune) near to the object.


Tones



The MI-6 audio PULSE tone can be adjusted from the remote control, tones range from 120 to 1582 Hz. (Audio PULSE mode only)

Press (-) or (+) to adjust the tone.


Audio PITCH / Audio PULSE



- Audio PITCH: The sound varies in tone and intensity, it is the default mode, it offers fast target location.
- **Audio PULSE:** Has a higher sound, intended for noisy environments. Target location is not as precise as PITCH mode. Pitch and Pulse mode both have the same performance.

Press (-) or (+) to switch from one mode to another.

Making and saving a custom program



PINPOINTER

CONFIG

AUDIO

._ Choose from one of the 3 factory pre-set programs in the menu to make your own custom program which can then be saved as (prg4).

- Select the program you want by pressing or +
- 2 Enter the settings by pressing MENU
- Save your settings by pressing **SAVE**

Note: When first used the MI-6 will start on program 2. After this it will start on the last used program.

Note: The 4 programs on the remote control are separate from the programs inside the pinpointer. When used independently the MI-6 (unpaired) will always use it's factory programs.